


ΛΕΙΤΟΥΡΓΙΕΣ ΠΛΗΚΤΡΩΝ

ΑΝΑΠΑΡΑΓΩΓΗ ΜΟΥΣΙΚΗΣ

Controller (+/-)		Πλήκτρο
Σύρετε τον controller προς το (+) για να δυναμώσετε την ένταση του ήχου	Σύρετε τον controller προς το (-) για να ελαττώσετε την ένταση του ήχου	• Ένα κλικ - αναπαραγωγή / παύση τραγουδιού • Δύο κλικ - μετάβαση στο επόμενο τραγούδι • Τρία κλικ - μετάβαση στο προηγούμενο τραγούδι

ΤΗΛΕΦΩΝΙΚΗ ΚΛΗΣΗ

Controller (+/-)		Πλήκτρο
Σύρετε τον controller προς το (+) για να δυναμώσετε την ένταση του ήχου	Σύρετε τον controller προς το (-) για να ελαττώσετε την ένταση του ήχου	• Ένα κλικ - αποδοχή / τερματισμός μιας κλήσης • Παρατεταμένο κλικ- αποστολή εισερχόμενης κλήσης στον αυτόματο τηλεφωνητή



IN-LINE CONTROLLER FUNCTIONS

AUDIO CONTROL

Controller (+/-)		Call button
Drag the controller to (+) to increase the volume	Drag the controller to (-) to reduce the volume	• One click - play/pause audio • Two clicks - skip to the next track • Three clicks - skip to the previous track

PHONE CALL CONTROL

Controller (+/-)		Call button
Drag the controller to (+) to increase the volume	Drag the controller to (-) to reduce the volume	• One click - accept/end a call • One click and hold - send incoming call to voicemail