


//SONORA

Wonderwall 400 FIXED

Fixed TV wall mount for 32" - 55"

EN
INSTALLATION MANUAL




Tools needed (not included)		Hardware (included)	
	Tape measure		Wall Plate x1
	Pencil		TV Bracket x2
	Drill		Level x1
	8mm Concrete Drill		
	3mm Wood Drill		
	Spanner 10mm		
	Screwdriver		
	Hammer		

1	2	3	4	5	6	7	8	


--	--	--	--

STEP1A Brick wall


1a



2a




3a




STEP1B Wood wall


1b



2b





3b





STEP2

Only one screw size fits your TV.



M4 M6 M8




STEP3A



STEP3B



STEP4





//SONORA Wonderwall 400 FIXED

Σταθερή Επιτοίχια βάση στήριξης,
για τηλεοράσεις LED/LCD από 32"-55"


ΕΛ

ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ




1ο(A) ΒΗΜΑ Στερέωση της βάσης σε τοίχο με τούβλα ή τσιμέντο


1α



2α




3α




1ο(B) ΒΗΜΑ Στερέωση της βάσης σε ξύλινο τοίχο / γυψοσανίδα


1β



2β



3β




2ο ΒΗΜΑ



M4 M6 M8





Μόνο ένα μέγεθος βίδας
ταιριάζει στην τηλεόρασή σας



3ο(A) ΒΗΜΑ



3ο(B) ΒΗΜΑ



4ο ΒΗΜΑ

