

//SONORA


Wonderwall

400 eMOTION

Motion TV wall mount with one arm,
for 32"- 55"

EN

INSTALLATION MANUAL




Tools needed (not included)		Hardware (included)	
	Tape measure		Wall Plate x1
	Pencil		TV Bracket x2
	Drill		Cable Hook x1
	10mm Concrete Drill		Level x1
	5mm Wood Drill		4mm Allen Key
	Screwdriver		
	Hammer		

ST7.3X57 (3PCS) 1	Ø10X50 (3PCS) 2	M4X25 (4PCS) 3	M6X25 (4PCS) 4	M8X30 (4PCS) 5	Ø16X6.5X1 (4PCS) 6	Ø18X9X10 (4PCS) 7	M5X45 (2PCS) 8


Max 400x400	Max 30Kg	32"-55"	87mm-260mm	8° to -8°

STEP1A Brick wall


1a



2a




3a




STEP1B Wood wall


1b



2b





3b





STEP2

Only one screw size fits your TV.



M4 M6 M8




STEP3A



STEP3B



STEP4






//SONORA

Wonderwall 400 eMOTION

Επιτοίχια βάση στήριξης με βραχίονα
για τηλεοράσεις LED/LCD από 32" έως 55"


ΕΛ

ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ




1ο(A) ΒΗΜΑ Στερέωση της βάσης σε τοίχο με τούβλα ή τσιμέντο


1α



2α




3α




1ο(B) ΒΗΜΑ Στερέωση της βάσης σε ξύλινο τοίχο / γυψοσανίδα


1β



2β



3β




2ο ΒΗΜΑ

M4 M6 M8





Πολύ κοντό Πολύ μακρύ Σωστό Σωστό



Μόνο ένα μέγεθος βίδας
ταιριάζει στην τηλεόρασή σας



STEP3A



STEP3B



4ο ΒΗΜΑ

